

Central Vacuum BOM for NADAIR-700AL-22 / Nadair 600AL-22

#	Name		QTY
1	COV-M2-NAD-V1		1
2	FOAM-COUMSER-TOP		1
3	FOAM-COUMSER-WAL		1
4	FOAM-CYLM2		1
5	BRA-MTRCOV-M2-V1		1
6	BRA-MTRRING-M1F-V1		1
7	GAS-MTRRING-SIL-V1		1
8	MTR-288 OR MTR-289		1
9	POL-MTR-M2-V1		1
10	GAS-MTR-5.7		1
11	PIP-01		1
12	PIP-39		1
13	GAS-PIP39		1
14	PAD-MUSUP-TOP-V3		1
15	MUSUP-V2		1
16	Sticker		1
17	PIP-89		1
18	GAS-PIP89		1
19	GAS-CAN-V1		1
20	PIP-10ALU-M2-V1		1
21	PIP-62		1
22	FD-12.5L		1
23	FP-8-NAD/LUM/NDR		1
24	PLG-110/120 OR PLG-220/240		1
25	PIP-STR/EG11 OR PIP-STR/SR6R1		1
26	6114-18HF OR 6114-15HF OR 6114-10HF		1
27	GAS-PCB 6114-V1		1
28	CAN-M2-NDR-V1		1
29	BRA-SUPCAN-V1		2
30	CANSUP-M2-V1		2
<b>Fastener</b>			
31	Screw for PIP-39	M4-12	4
32	Screw for Cover	M6-30	1
33	Ground screw	M4-20	1
34	Screw for POL-MTR	M5-16	8
35	Alu rivet (Alu Pin)	M4-13	4
36	Alu rivet	M4-12	8
37	Alu rivet	M3.2-6	2
38	Stainness steel rivet	M4-12	4
39	ST4.8-38	ST4.8-38	3
40	Washer	Nylon M4	4
41	Nut	Nut M4	3
42	Nylon washer	M4	1
43	Star washer	M4	4
44	Washer	M4	2
45	Big wagher	M4	8

